



DIPOLE ANTENNAS

In [radio](#) and [telecommunications](#) a **dipole antenna** or **doublet**^[1] is the simplest and most widely used class of [antenna](#).^{[2][3]} The dipole is any one of a class of antennas producing a radiation pattern approximating that of an elementary electric dipole with a radiating structure supporting a line current so energized that the current has only one node at each end.^[4] A dipole antenna commonly consists of two identical conductive elements^[5] such as metal wires or rods.^{[3][6][7]} The driving current from the [transmitter](#) is applied, or for receiving antennas the output signal to the [receiver](#) is taken, between the two halves of the antenna. Each side of the [feedline](#) to the transmitter or receiver is connected to one of the conductors. This contrasts with a [monopole antenna](#), which consists of a single rod or conductor with one side of the feedline connected to it, and the other side connected to some type of ground.^[8] A common example of a dipole is the "rabbit ears" [television antenna](#) found on broadcast television sets.

The dipole is the simplest type of antenna from a theoretical point of view.^[1] Most commonly it consists of two conductors of equal length oriented end-to-end with the feedline connected between them.^{[9][10]} Dipoles are frequently used as [resonant antennas](#). If the feedpoint of such an antenna is shorted, then it will be able to [resonate](#) at a particular frequency, just like a guitar [string](#) that is plucked. Using the antenna at around that frequency is advantageous in terms of feedpoint impedance (and thus [standing wave ratio](#)), so its length is determined by the intended [wavelength](#) (or frequency) of operation.^[3] The most commonly used is the center-fed **half-wave dipole** which is just under a half-wavelength long. The [radiation pattern](#) of the half-wave dipole is maximum perpendicular to the conductor, falling to zero in the axial direction, thus implementing an [omnidirectional antenna](#) if installed vertically, or (more commonly) a weakly directional antenna if horizontal.^[11]

Although they may be used as standalone [low-gain](#) antennas, dipoles are also employed as [driven elements](#) in more complex antenna designs^{[3][5]} such as the [Yagi antenna](#) and driven [arrays](#). Dipole antennas (or such designs derived from them, including the monopole) are used to feed more elaborate [directional antennas](#) such as a [horn antenna](#), [parabolic reflector](#), or [corner reflector](#). Engineers analyze vertical (or other [monopole](#)) antennas on the basis of dipole antennas of which they are one half